## Zweiflügeltore System Classic (typische Abmessungen)

Ausführung	Breite zwischen den Pfosten x Flügelhöhe (So x H) in [mm]													
	3000x 1200	3000x 1450	3500x 1200	3500x 1450	4000x 1200	4000x 1450	4500x 1200	4500x 1450	5000x 1450	5000x 1750	5500x 1450	5500x 1750	6000x 1450	6000x 1750
C 1001	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>✓</b>
C 1002	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>
C 1004	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	<b>√</b>	✓	✓	✓	<b>√</b>
C 1005	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>
C 1006	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>
C 1016	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>
C 1017	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>
C VA55	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>
C 1070	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	-	✓	-	✓	-
C 1071	<b>√</b>	✓	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	_	✓	_	✓	_
C 1072	<b>√</b>	✓	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	_	✓	_	✓	_
C 10TT	<b>√</b>	✓	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>

## Zweiflügeltore System Classic (Sonderabmessungen)

Torflügel- höhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]												
	Ausführung	von 2400 bis 3500	3600 3700	3800 3900 4000	4100 4200	4300 4400 4500	4600 4700	4800 4900 5000	5100 5200	5300 5400 5500	5600 5700	5800 5900 6000	
	C 1001	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	<b>√</b>	
	C 1002	✓	<b>√</b>	✓	✓	✓	✓	✓	✓	✓	✓	<b>√</b>	
	C 1004	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	✓	<b>√</b>	
	C 1005	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	
	C 1006	<b>✓</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	
	C 1016	<b>✓</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	
	C 1017	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	
	C 1070	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	
1000 1050	C 1071	<b>✓</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	
	C 1072	<b>✓</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	
	C VA55	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	<b>√</b>	
1300 1350 1400 1450	C 10TT	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	

## Zweiflügeltore System Classic (Sonderabmessungen)

Torflügel-	Abstand (Breite) zwischen den Pfosten (So) in [mm]												
höhe (H) in [mm] -	Ausführung	von 2400 bis 3500	3600 3700	3800 3900 4000	4100 4200	4300 4400 4500	4600 4700	4800 4900 5000	5100 5200	5300 5400 5500	5600 5700	5800 5900 6000	
	C 1001	✓	✓	✓	✓	✓	✓	✓	<b>√</b>	✓	<b>√</b>	✓	
	C 1002	✓	✓	✓	✓	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1004	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	
	C 1005	✓	<b>√</b>	✓	✓	✓	✓	✓	✓	<b>√</b>	✓	✓	
	C 1006	✓	✓	✓	✓	<b>✓</b>	<b>√</b>	✓	<b>✓</b>	<b>✓</b>	✓	✓	
ı	C 1016	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>✓</b>	<b>√</b>	✓	
	C 1017	✓	✓	✓	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1070	✓	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>✓</b>	✓	✓	
	C 1072	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C VA55	✓	<b>√</b>	<b>√</b>									
1500 1550 1600	C 10TT	✓	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1001	✓	✓	✓	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1002	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1004	<b>√</b>	✓	✓	✓	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1005	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>✓</b>	<b>✓</b>	✓	
	C 1006	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1016	<b>√</b>	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1017	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>✓</b>	<b>✓</b>	✓	
1650 1700 - 1750	C VA55	✓	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>✓</b>	✓	✓	
	C 10TT	<b>√</b>	✓	✓	✓	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C 1001	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>✓</b>	<b>√</b>	✓	
	C 1004	✓	✓	✓	✓	✓	<b>√</b>	✓	✓	✓	<b>√</b>	✓	
	C 1006	✓	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	✓	
	C 1016	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	✓	
	C 1017	✓	✓	✓	<b>√</b>	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
	C VA55	✓	✓	✓	<b>√</b>	<b>√</b>	✓	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	
1800 1850 1900 1950	C 10TT	✓	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	✓	<b>√</b>	<b>√</b>	<b>√</b>	<b>√</b>	