

Pforten System Lux (Sonderabmessungen)

Flügelhöhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1000 1050 1100 1150 1200 1250 1300 1350 1400 1450	L 1031	✓	✓	✓	✓
	L 1033	✓	✓	✓	✓
	L 1034	✓	✓	✓	✓
	L 1039	✓	✓	✓	✓
	L 1045	✓	✓	✓	✓
	L 1046	✓	✓	✓	✓
	L 1048	✓	✓	✓	✓
	L 1051	✓	✓	✓	✓
	L 1052	✓	✓	✓	✓
	L 1053	✓	✓	✓	✓
	L 1054	✓	✓	✓	✓
	L 1056	✓	✓	✓	✓
	L 1057	✓	✓	✓	✓
	L 1058	✓	✓	✓	✓
	L 1059	✓	✓	✓	✓
	L 1060	✓	✓	✓	✓
	L 1061	✓	✓	✓	✓
	L 1062	✓	✓	✓	✓

Pforten System Lux (Sonderabmessungen)

Flügelhöhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1500 1550 1600	L 1031	✓	✓	✓	✓
	L 1033	✓	✓	✓	✓
	L 1034	✓	✓	✓	✓
	L 1039	✓	✓	✓	✓
	L 1045	✓	✓	✓	✓
	L 1046	✓	✓	✓	✓
	L 1048	✓	✓	✓	✓
	L 1051	✓	✓	✓	✓
	L 1052	✓	✓	✓	✓
	L 1053	✓	✓	✓	✓
	L 1054	✓	✓	✓	✓
	L 1056	✓	✓	✓	✓
	L 1057	✓	✓	✓	✓
	L 1058	✓	✓	✓	✓
	L 1059	✓	✓	✓	✓
	L 1060	✓	✓	✓	✓
	L 1061	✓	✓	✓	✓
	L 1062	✓	✓	✓	✓

Pforten System Lux (Sonderabmessungen)

Flügelhöhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800	950	1100	1250
		850	1000	1150	1300
1650 1700 1750		900	1050	1200	1350
	L 1031	✓	✓	✓	✓
	L 1033	✓	✓	✓	✓
	L 1034	✓	✓	✓	✓
	L 1039	✓	✓	✓	✓
	L 1045	✓	✓	✓	✓
	L 1046	✓	✓	✓	✓
	L 1048	✓	✓	✓	✓
	L 1051	✓	✓	✓	✓
	L 1052	✓	✓	✓	✓
	L 1053	✓	✓	✓	✓
	L 1054	✓	✓	✓	✓
	L 1056	✓	✓	✓	✓
	L 1057	✓	✓	✓	✓
	L 1058	✓	✓	✓	✓
	L 1059	✓	✓	✓	✓
	L 1060	✓	✓	✓	✓
	L 1061	✓	✓	✓	✓
	L 1062	✓	✓	✓	✓

Pforten System Lux (Sonderabmessungen)

Flügelhöhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1800 1850 1900 1950	L 1031	✓	✓	✓	✓
	L 1033	✓	✓	✓	✓
	L 1034	✓	✓	✓	✓
	L 1039	✓	✓	✓	✓
	L 1045	✓	✓	✓	✓
	L 1046	✓	✓	✓	✓
	L 1048	✓	✓	✓	✓
	L 1051	✓	✓	✓	✓
	L 1052	✓	✓	✓	✓
	L 1053	✓	✓	✓	✓
	L 1054	✓	✓	✓	✓
	L 1056	✓	✓	✓	✓
	L 1057	✓	✓	✓	✓
	L 1058	✓	✓	✓	✓
	L 1059	✓	✓	✓	✓
	L 1060	✓	✓	✓	✓
	L 1061	✓	✓	✓	✓
	L 1062	✓	✓	✓	✓