

Pforten System Style (typische Abmessungen)

Ausführung	Breite zwischen den Pfosten x Flügelhöhe (So x H) in [mm]				
	1000x1200	1000x1450	1000x1750	1200x1450	1200x1750
S 1007/P	✓	✓	✓	✓	✓
S 1008/P	✓	✓	✓	✓	✓
S 1009/P	✓	✓	✓	✓	✓
S 1012/P	✓	✓	✓	✓	✓
S 1014/P	✓	✓	✓	✓	✓
S 1015/P	✓	✓	✓	✓	✓
S 1020/P	✓	✓	✓	✓	✓
S 1021/P	✓	✓	✓	✓	✓
S 1022/P	✓	✓	✓	✓	✓
S 1023/P	✓	✓	✓	✓	✓
S 1024/P	✓	✓	✓	✓	✓
S 1025/P	✓	✓	✓	✓	✓
S 1026/P	✓	✓	✓	✓	✓

P - gerade Ausführung des oberen Randes.

Pforten System Style (Sonderabmessungen)

Flügelhöhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1000 1050 1100 1150 1200 1250 1300 1350 1400 1450	S 1007	✓	✓	✓	✓
	S 1008	✓	✓	✓	✓
	S 1009	✓	✓	✓	✓
	S 1012	✓	✓	✓	✓
	S 1014	✓	✓	✓	✓
	S 1015	✓	✓	✓	✓
	S 1020	✓	✓	✓	✓
	S 1021	✓	✓	✓	✓
	S 1022	✓	✓	✓	✓
	S 1023	✓	✓	✓	✓
	S 1024	✓	✓	✓	✓
	S 1025	✓	✓	✓	✓
	S 1026	✓	✓	✓	✓

Pforten System Style (Sonderabmessungen)

Flügelhöhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1500 1550 1600	S 1007	✓	✓	✓	✓
	S 1008	✓	✓	✓	✓
	S 1009	✓	✓	✓	✓
	S 1012	✓	✓	✓	✓
	S 1014	✓	✓	✓	✓
	S 1015	✓	✓	✓	✓
	S 1020	✓	✓	✓	✓
	S 1021	✓	✓	✓	✓
	S 1022	✓	✓	✓	✓
	S 1023	✓	✓	✓	✓
	S 1024	✓	✓	✓	✓
	S 1025	✓	✓	✓	✓
	S 1026	✓	✓	✓	✓

Pforten System Style (Sonderabmessungen)

Flügelhöhe (H) in [mm]	Abstand (Breite) zwischen den Pfosten (So) in [mm]				
	Ausführung	800 850 900	950 1000 1050	1100 1150 1200	1250 1300 1350
1650 1700 1750	S 1007	✓	✓	✓	✓
	S 1008	✓	✓	✓	✓
	S 1009	✓	✓	✓	✓
	S 1012	✓	✓	✓	✓
	S 1014	✓	✓	✓	✓
	S 1015	✓	✓	✓	✓
	S 1020	✓	✓	✓	✓
	S 1021	✓	✓	✓	✓
	S 1022	✓	✓	✓	✓
	S 1023	✓	✓	✓	✓
	S 1024	✓	✓	✓	✓
	S 1025	✓	✓	✓	✓
	S 1026	✓	✓	✓	✓